

# BLOWER WHEELS



## DOUBLE INLET BLOWER WHEELS

Aluminum with Steel Hubs – 4<sup>3/4</sup>" - 7<sup>1/2</sup>" Diameter



### 4<sup>3/4</sup>" - 7<sup>1/2</sup>" DIAMETER

Lau Part Number	Diameter	Width	Rotation	Bore	RPM
028958-08	4 <sup>3/4</sup> "	5 <sup>1/8</sup> "	CW	1/2"	3450
028958-14	4 <sup>3/4</sup> "	5 <sup>1/8</sup> "	CCW	1/2"	3450
028958-01	4 <sup>3/4</sup> "	6 <sup>7/8</sup> "	CW	1/2"	3450
028958-15	4 <sup>3/4</sup> "	6 <sup>7/8</sup> "	CCW	1/2"	3450
028958-02	5 <sup>1/4</sup> "	5 <sup>7/8</sup> "	CW	1/2"	3450
028958-16	5 <sup>1/4</sup> "	5 <sup>7/8</sup> "	CCW	1/2"	3450
028958-17	5 <sup>1/4</sup> "	6 <sup>3/4</sup> "	CCW	1/2"	3450
028958-18	5 <sup>1/4</sup> "	6 <sup>3/4</sup> "	CW	1/2"	3450
028958-03	5 <sup>1/4</sup> "	6 <sup>7/8</sup> "	CW	1/2"	3450
028958-19	5 <sup>1/4</sup> "	6 <sup>7/8</sup> "	CCW	1/2"	3450
028958-04	5 <sup>3/4</sup> "	5 <sup>7/8</sup> "	CW	1/2"	3450
028958-20	5 <sup>3/4</sup> "	5 <sup>7/8</sup> "	CCW	1/2"	3450
028958-05	5 <sup>3/4</sup> "	6 <sup>7/8</sup> "	CW	1/2"	3450
028958-21	5 <sup>3/4</sup> "	6 <sup>7/8</sup> "	CCW	1/2"	3450
028958-22	5 <sup>3/4</sup> "	7 <sup>5/8</sup> "	CW	1/2"	3450
028958-23	5 <sup>3/4</sup> "	7 <sup>5/8</sup> "	CCW	1/2"	3450
028958-24	5 <sup>3/4</sup> "	8"	CW	1/2"	3450
028958-25	5 <sup>3/4</sup> "	8"	CCW	1/2"	3450
028958-06	5 <sup>3/4</sup> "	8 <sup>1/2</sup> "	CW	1/2"	3450
028958-26	5 <sup>3/4</sup> "	8 <sup>1/2</sup> "	CCW	1/2"	3450
028958-27	6 <sup>5/16</sup> "	6 <sup>3/8</sup> "	CW	3/4"	3450
028958-28	6 <sup>5/16</sup> "	6 <sup>3/8</sup> "	CCW	3/4"	3450
028958-07	6 <sup>5/16</sup> "	7 <sup>5/8</sup> "	CW	1/2"	3450
028958-29	6 <sup>5/16</sup> "	7 <sup>5/8</sup> "	CCW	1/2"	3450
028958-32	7 <sup>1/2</sup> "	4"	CW	3/4"	2500
028958-33	7 <sup>1/2</sup> "	4"	CCW	3/4"	2500
028958-34	7 <sup>1/2</sup> "	5"	CW	3/4"	2500
028958-35	7 <sup>1/2</sup> "	5"	CCW	3/4"	2500
028958-36	7 <sup>1/2</sup> "	6 <sup>11/32</sup> "	CW	3/4"	1800
028958-37	7 <sup>1/2</sup> "	6 <sup>11/32</sup> "	CCW	3/4"	1800

Maximum Operating Temperature – 150°F.


#### TECHNICAL TIPS:

**For other sizes:** Double inlet wheels may be duplicated in the field by:

1. Using one CW and one CCW single wheel – may be different widths to make up space required, but diameters must be the same (see Pages 35-36).
2. For wheels too close to apparatus to reach with driver, tighten wheels to shaft by using extended "T" Allen wrench inserted through a notch in one of the blades in each wheel.

#### ▲ CAUTION:

To avoid potential vibration, allow slight air gap (min. 1/32") between wheels.



**NOTE:** To determine rotation for Double Wheels, view from hub.

Specifications are subject to change without notice or obligation.